# 2K InvisibleProtect

ADVANCED TECHNOLOGY





Latest-generation, waterborne surface protection for parquet and hardwood floors. For extremely heavy wear. The natural look and feel of the untreated wood is maintained. The virtually invisible layer is also extremely scratch-resistant thanks to the use of the highest-quality raw materials. Elastic, excellent chemical and abrasion resistance.

- · Natural structure and feel like untreated wooden flooring
- Easy to work with
- 2 coat system without primer
- Certified non-slip properties as per BGR 181 for work areas
- No polishing effect
- · Excellent chemical resistance
- As easy to clean as finished surfaces
- No grain accentuation, the original colour of the wood remains as it was in its original state

#### Range of use:

Suitable for parquet, wood and cork flooring. Anti-slip as per BGR 181 and DIN 51130 evaluation group R9. Suitable for virtually all types of European and exotic timber. Note the LOBA wood types list, which can be found at www.loba.de. If in doubt, consult the factory.











#### Technical Data

Artno.		$-\Box$	
11474	1 kg	6	360
	5 kg	2	96

# 2K InvisibleProtect



#### Technical Data

Gloss level approx.\* 9

Solids  $32 \pm 2\%$  Viscosity DIN 4  $28 \pm 2s$ 

Storage and transportation 12 months of storage stability. No hazardous material according to ADR. Store and transport

ADVANCED

TECHNOLOGY

between +5 to +25°C. Protect from frost.

GISCODE W2/DD+

2004/42/CE EU limit value for this product (cat. A/j): 140 q/l (2010).

This product contains max.47 g/l of VOC (mixed with hardener).

### **Application**

- Shake product, add hardener to base at a ratio of 10 : 1 and then shake to mix. For mixing smaller quantities, use the LOBATOOL Mixing Container or a scale to weigh out the components. Usable up to 2 hours after mixing.
- The surface must be sanded properly, wood moisture content max. 12%.
- The floor must be dry and free from any old coatings, oil, grease, wax, silicone, sanding dust and other contaminants. Room temperature +15°C to +25°C, relative humidity 40% to 75%, material temperature +18°C to +25°C. Ensure working areas are adequately ventilated.
- Transfer material to a LOBATOOL varnish bucket before applying.
- · Shake the contents well.
- Observe the general and, if available, the product-specific health and safety instructions. More specific information relating to GISCODE can be found in the usage instructions, which are available at www.wingis-online.de.

#### Thinner

The product is supplied ready for use and must not be diluted!

### Application tool/application rate

LOBATOOL roller Deluxe 120 / 100 - 120 ml(g)/m2 = 8-10 m2/l (kg)

#### Intermediate sanding

Able to recoat without intermediate sanding within the first 24 hours. After this time, an intermediate sanding is necessary. An intermediate sanding before the last application will achieve an even finish. Use LOBATOOL perforated pad P120 or finer, alternatively Sanding Net P120 or finer. Carefully remove dust before overcoating.



<sup>\*</sup> The degree of gloss is measured at 60° on glass. It depends on the layer thickness and ambient conditions (temp., rel. humidity) during the drying process. The values are intended merely as a quide.

# 2K InvisibleProtect



## **Application**

### Drying time

- Earliest possible recoating after 4-6 hours.
- Careful use possible after 4-6 hours.
- Earliest possible intermediate sanding after 8-10 hours.
- Light use after 24 hours.
- Full use and covering possible after 5 days.
- The floor can be covered earlier by using LOBATOOL Cover 400, for details see the TI for the product.

#### Set-up recommendation without a primer, areas of normal to extremely heavy wear:

ADVANCED TECHNOLOGY

Possible for rigid or shear-resistant adhesive. 2K InvisibleProtect A.T. is especially effective on light timbers such as oak, ash, maple and light beech.

- Prepare the substrate correctly.
- Roll on 2K InvisibleProtect A.T.
- Dry for 8-10 hours
- Intermediate sanding
- Roll on 2K InvisibleProtect A.T.

#### Use on cork:

Seal only after the adhesive has set adequately.

#### Untreated natural cork:

- Apply two layers of 2K InvisibleProtect A.T. by roller.
- Allow the first layer to dry overnight (reduces the risk of granule swelling).
- Intermediate sanding before the final application.

#### Prefinished cork

Observe the cork supplier's instructions. If suitable for recoating, apply one layer of 2K InvisibleProtect A.T. after an intermediate sanding.

#### Renovation / recoating of old coatings

Basic cleaning with CareRemover. Use a rotary disk buffing machine and a LOBATOOL Special Pad green. Care product residues must be completely removed. Even small amounts of residue can adversely effect the bond of the coating. Clean with clear water (neutralise). After drying, carry out a thorough intermediate sanding. Apply one layer of 2K InvisibleProtect A.T. by roller.

#### Alternative Set-up recommendation, areas of normal wear:

With reduced side bonding and intensification of the wood colour. The structure combines the look and feel of an oiled surface with the cleaning properties of finished surfaces.

- Prepare the substrate and sand properly.
- Prime with LOBADUR® HS 2K Intensive A.T.
- Dry as per the technical information.
- Roll on 2K InvisibleProtect A.T..



# 2K InvisibleProtect



## **Application**

### Important information

In case of strong roughening of the wood, optionally apply a further layer of 2K InvisibleProtect A.T. after an intermediate sanding. Layer-building care products would change the unique extramatt surface to a shinier optic. For this reason, we recommend not using them. Instead, perform an intermediate sanding according to the level of stress and apply another coat of with 2K InvisibleProtect A.T. afterwards.

ADVANCED

TECHNOLOGY

## General guidelines

**Cleaning of tools:** Clean tools and equipment immediately with water.

**Drying time:** The indicated drying times are valid for +20°C and 55% to 65% relative humidity, and assume careful, draught-free ventilation of the working area. Lower temperatures, higher relative humidity or poorer ventilation lead to longer drying times. Do not apply any protective coverings, wet clean the surface or lay carpet until the coating has achieved its final hardening. Product-specific data can be found in the relevant technical information.

**Intermediate sanding:** Where several layers of coatings are applied, if any layer is not overcoated within 24 hours, then the only way to ensure adequate bond between the layers is by intermediate sanding. An intermediate sanding before the final application will achieve an even surface. Carefully clean off the dust after intermediate sanding.

**Interactions:** Materials such as carpet underlays, furniture legs, castors, flexible adhesives used for parquet or for fixing can lead to softening and discolouration. Material building up in the joints can adversely affect touch and appearance. Exposure to hair dyes or rubber tyres on cars, motorcycles and cycles can lead to permanent, irreversible discolouration of the surface.

The information in this document and all other advice and recommendations that we provide to help and assist the applicator are based on previous experience and relate to normal conditions. Because of the wide range of possible uses and conditions of application of our products, we do not relieve users from the need to carry out their own trials or to seek technical advice by speaking to the LOBA application engineering department. Observe the floor covering manufacturer's recommendations and the provisions of the current standards. Our liabilities and responsibilities are exclusively in accordance with our Terms and Conditions and are not extended by this information or by our advice. The publishing of a new technical data sheet automatically invalidates the earlier version.