

## STAUF VPU-155 S Polyurethane primer (14300)

Solvent free polyurethane primer

### Special features

- damp proof membrane on cement sub floors with residual moisture
- very economical
- universal use



### Application range

- damp proof membrane on cement sub floors with residual moisture of max. 3,5 CM-%
- primer below STAUF PU-, SPU- and SMP-adhesives
- primer underneath to levelling with STAUF levelling compounds (sanded)

### Suitable sub floors

- mastic asphalt screed
- concrete C 25 / 30 according to DIN 1045 (non-skid surface)
- calcium sulphate (flow) floors (no moisture barrier)
- wooden planks, solid wood fibre boards
- chipboards V100 (E1), OSB boards
- unlaminated gypsum fibre boards
- cement floors

### Product properties

- suitable for sub floor heating systems
- ready for use
- solvent-free
- creates a dust free surface ready for installation using STAUF polyurethane, SPU or SMP based adhesives
- very low emission

### Color

- honey

### Required quantities per m²

#### Drying time

- approx. 30-45 min. at 20 °C; 2nd layer (DPM): approx 2 h at 20 °C

#### Additional instructions 1

- approx. 150 g when applied with roller; 2nd layer (damp proof membrane): approx. 250 g when applied with roller

#### Room climate at work site

- minimum 15 °C, maximum 75% rel. humidity, preferably max. 65%

#### Transport hazard category

- 

#### Shelf-life

- 9 months

#### Giscode

- RU1

#### Emicode

- EC1-R plus

#### Available packaging

-

## Examination of sub floor

Prior to processing, the sub floor must be checked according to the standard DIN 18356, DIN 18365, DIN 18367 or corresponding national standards. The sub floor shall be resistant to pressure and tension, free of cracks, must have sufficient surface strength, be permanently dry, level, clean and free of anti-adherents, sinter layers etc. In addition, porosity and grip of surface need to be checked. Also check moisture content and absorptive capacity of cement (flow) and calciumsulfate (flow) floors as well as room temperature, air humidity and sub floor temperature. Calciumsulfate (flow) floors and magnesite floors must be permanently dry, cement floors with residual moisture may receive as damp proof membrane by applying the STAUF primer. The maximum admissible residual moisture for cement floors is 3,5 CM-%.

## Sub floor preparation

It must be ensured that the sub floor is ready for installation by performing proper sub floor preparation, floors must be clean, have sufficient surface strength, must be level, permanently dry and free of cracks. A mechanical pretreatment of the subfloor (sweeping, vacuuming, mechanical brushing, sanding, milling, shot blasting) must be performed depending on type and condition of sub floor. Cracks and joints, except expansion joints and other construction joints, shall be solidly closed with STAUF casting resin and floor brackets. Cavities and indentations can be filled with a non self-levelling STAUF levelling compound.

## Processing

Apply ready-to-use or mixed primer once with a lambskin roller during processing time, avoid puddles. Alternatively, a foam roller, brush or smooth blade can be used. Immediately after applying the primer, generously sprinkle with dry STAUF quartz sand (grain size 0.4 - 0.8 mm, consumption approx. 2.5 - 3kg/m<sup>2</sup>). When the primer is used as vapor barrier, sprinkling of the first layer is not required. At the earliest after 1 hours, at the latest after 48 hours, a second layer is applied which is then sprinkled with sand immediately after application. At the earliest after 2 hours, all excess sand is brushed and vacuumed off. After sand is removed, the surface can be leveled with STAUF leveling compounds or STAUF PUK-, SPU or SMP adhesives can be applied directly. Within 24-48 hours after application, PUK, SPU or SMP adhesives can be applied on primer without prior application of quartz sand.

## Other information

Barriers for residual moisture in cement-based screed cannot rule out damage to parquet flooring that is caused by a level of building moisture that is generally too high. Contact STAUF applications technology in the event of heated cement-based screeds with excessive residue moisture.

## Limitation of liability

The foregoing representations are based on the results of our most current product and material testing and are of a non-obligatory advisory nature only since we have no control over the actual quality of workmanship, materials used and worksite conditions. As such, they do not constitute an express or implied warranty of any kind. The same applies to our commercial and technical consultation services which are provided free-of-charge and without obligation. Therefore, we strongly recommend that prior on-site testing be conducted to observe and study the suitability of the product for the intended purpose. With the release of this technical information, all prior technical information (technical data sheets, installation recommendations and other information regarding similar purposes) becomes invalid.